Vehicle: 1991 Porsche 962C

VIN: 962166

Date project started: 7/10/12 Date project finished: 8/7/12

Project Outline

Inspection:

- Position vehicle in work shop and hoist onto work stands.
- Remove wheels and bodywork.
- Perform "nut & bolt" inspection.

Fuel System:

- Pump out and dispose of old fuel.
- Replace fuel filters.
- Replace leaking fuel filter fitting.

Engine:

- Remove under trays to gain access to engine oil system drain.
- Drain oil and inspect for particles.
- Remove, inspect, clean, and reinstall oil filter element.
- Refill oil system.

Shock Absorbers:

- Remove front and rear shock absorbers.
- Document spring heights.
- Sublet shocks for complete overhaul.
- Install overhauled shocks.

Transaxle:

- Drain and inspect oil from transaxle.
- Refill transaxle.

Brakes:

- Assemble and install new left front brake hose.
- Flush and bleed brake system.

Nose:

- Sublet for repair of fiberglass on right fender of nose.
- Perform bodywork on right fender of nose panel.
- Prep and paint right side of nose.

Winglets:

- Remove winglets from nose.
- Sublet for carbon fiber repair.
- Prep and paint winglets.

Detail:

- Steam clean and hand wash engine assembly and suspension components.
- Blow, vacuum, and wipe down inside of tub.
- Apply penetrating oil to magnesium components.
- Clean wheel and tire assemblies.
- Wash exterior.
- Clean windows.

Vehicle: 1991 Porsche 962C Date project started: 7/9/12 Date project finished: 8/20/12

Project Outline

2012 Rolex Monterey Motorsports Reunion

Provide, transportation, team support personnel, trackside car preparation, maintenance, cleaning services, driver assistance, workshop, dressing area, awnings, etc. Provide 23 gallons of race fuel during event.

Lap Times

8/19/12, 10:40 am.		
1: Out Lap.	6:	1:30.31
2: 1:39.20	7:	1:30.47
3: 1:30.85	8:	1:29.46
4: 1:33.35	9:	1:29.50
5: 1:30.69	10:	1:27.06
	11:	1:27.57
	12:	Pit.

8/19/12, 3:10 pm.

1: Out Lap.	 6:	1:29.19
2: 1:34.79	7:	1:29.56
3: 1:31.00	8:	1:30.85
4: 1:30.63	9:	1:29.88
5: 1:30.17	10:	1:29.75
	11:	1:30.33

Vehicle: 1991 Porsche 962C

VIN: 962-166

Date project started: 8/20/2012 Date project finished: 9/4/12

Project Outline

Inspection:

- Position vehicle in works shop, remove bodywork, place on work stands, and remove wheels.
- Perform visual inspection.
- Start and run engine.

Detail:

- Steam clean engine and transaxle assembly.
- Apply penetrating oil to magnesium surfaces.
- Blow and vacuum interior.
- "Showroom" exterior.
- Clean windows.

Battery:

- Remove original battery.
- Clean battery area.
- Clean and paint battery hold down.
- Install new battery.