

Honda Idler Assembly

Certain K20 A engines that do not have power steering have instead an idler assembly.
Honda part numbers”

	<u>Description</u>		<u>Qty</u>	<u>part no.</u>
1.	31175-PRA-000	bracket	1	700364
2.	31185-PCX-003	cover	1	623476
3.	31190-PRA-000	pulley	1	700365
4.	90031-PRA-000W	bolt	1	700494
5.	95701-08045-0W	bolt	1	260225
6.	95701-12060-0W	bolt	1	264750

